

24V A-C/D-C Input Module

M/N 57C415

Instruction Manual J-3622-1

RELIANCE
ELECTRIC 

The information in this user's manual is subject to change without notice.

WARNING

THIS UNIT AND ITS ASSOCIATED EQUIPMENT MUST BE INSTALLED, ADJUSTED AND MAINTAINED BY QUALIFIED PERSONNEL WHO ARE FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF ALL EQUIPMENT IN THE SYSTEM AND THE POTENTIAL HAZARDS INVOLVED. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

WARNING

INSERTING OR REMOVING THIS MODULE OR ITS CONNECTING CABLES MAY RESULT IN UNEXPECTED MACHINE MOTION. POWER TO THE MACHINE SHOULD BE TURNED OFF BEFORE INSERTING OR REMOVING THE MODULE OR ITS CONNECTING CABLES. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

CAUTION

THIS MODULE CONTAINS STATIC-SENSITIVE COMPONENTS. CARELESS HANDLING CAN CAUSE SEVERE DAMAGE.

DO NOT TOUCH THE CONNECTORS ON THE BACK OF THE MODULE. WHEN NOT IN USE, THE MODULE SHOULD BE STORED IN AN ANTI-STATIC BAG. THE PLASTIC COVER SHOULD NOT BE REMOVED. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN DAMAGE TO OR DESTRUCTION OF THE EQUIPMENT.

Table of Contents

1.0	Introduction	1-1
2.0	Mechanical/Electrical Description	2-1
2.1	Mechanical Description	2-1
2.2	Electrical Description	2-1
3.0	Installation	3-1
3.1	Wiring	3-1
3.2	Initial Installation	3-1
3.3	Module Replacement	3-4
4.0	Programming	4-1
4.1	Register Organization	4-1
4.2	Configuration	4-1
4.3	Reading Data In Application Tasks	4-1
4.3.1	Ladder Logic Task Example	4-2
4.3.2	BASIC Task Example	4-2
4.3.3	Control Block Task Example	4-2
4.4	Restrictions	4-2
5.0	Diagnostics And Troubleshooting	5-1
5.1	Incorrect Data	5-1
5.2	Bus Error	5-2

Appendices

Appendix A	
Technical Specifications	A-1
Appendix B	
Module Block Diagram	B-1
Appendix C	
Field Connections	C-1
Appendix D	
Related Components	D-1
Appendix E	
Defining Variables in the Configuration Task	E-1

List of Figures

Figure 2.1	- Typical Input Circuit	2-1
Figure 2.2	- Module Faceplate	2-2
Figure 3.1	- Typical Field Signal Connections	3-2
Figure 3.2	- Rack Slot Numbers	3-3
Figure 4.1	- Organization of Register Bits	4-1

1.0 INTRODUCTION

The products described in this instruction manual are manufactured or distributed by Reliance Electric Company or its subsidiaries.

This 12-24V A-C/D-C Input Module will accept up to a maximum of sixteen 24 volt control signals as inputs to the DCS 5000/AutoMax system. The input signals may be 50 or 60 hertz A-C or D-C. Input signals have 2500 volt isolation to logic common. The module contains four isolated commons, each having four inputs.

Typically, this module is used to input on/off signals from devices such as relay contacts, limit switches, push-buttons, and selector switches.

This manual describes the functions and specifications of the module. It also includes a detailed overview of installation and servicing procedures, as well as examples of programming methods.

Related publications that may be of interest:

- J-2611 DCS 5000 PRODUCT SUMMARY
- J-3600 DCS 5000 ENHANCED BASIC LANGUAGE INSTRUCTION MANUAL
- J-3601 DCS 5000 CONTROL BLOCK LANGUAGE INSTRUCTION MANUAL
- J-3602 DCS 5000 SYSTEM OVERVIEW
- J-3629 DCS 5000 REMOTE I/O INSTRUCTION MANUAL
- J-3630 ReSource AutoMax PROGRAMMING EXECUTIVE INSTRUCTION MANUAL VERSION 1.0
- J-3635 DCS 5000 PROCESSOR MODULE INSTRUCTION MANUAL
- J-3649 AutoMax CONFIGURATION TASK MANUAL
- J-3650 AutoMax PROCESSOR MODULE INSTRUCTION MANUAL
- J-3675 AutoMax ENHANCED BASIC LANGUAGE INSTRUCTION MANUAL
- J-3676 AutoMax CONTROL BLOCK LANGUAGE INSTRUCTION MANUAL
- J-3677 AutoMax LADDER LOGIC LANGUAGE INSTRUCTION MANUAL
- J-3684 ReSource AutoMax PROGRAMMING EXECUTIVE INSTRUCTION MANUAL VERSION 2.0
- J-3750 ReSource AutoMax PROGRAMMING EXECUTIVE INSTRUCTION MANUAL VERSION 3.0
- IEEE 518 GUIDE FOR THE INSTALLATION OF ELECTRICAL EQUIPMENT TO MINIMIZE ELECTRICAL NOISE INPUTS TO CONTROLLERS FROM EXTERNAL SOURCES

2.0 MECHANICAL/ELECTRICAL DESCRIPTION

The following is a description of the faceplate LEDs, field termination connectors, and electrical characteristics of the field connections.

2.1 Mechanical Description

The input module is a printed circuit board assembly that plugs into the backplane of the DCS 5000/AutoMax rack. It consists of a printed circuit board, a faceplate, and a protective enclosure. The faceplate contains tabs at the top and bottom to simplify removing the module from the rack. Module dimensions are listed in Appendix A.

The faceplate of the module contains a female connector socket and sixteen LED indicators that show the status of the inputs. Input signals are brought into the module via a multi-conductor cable (M/N 57C370; see Appendix D). One end of this cable attaches to the faceplate connector, while the other end of the cable has stake-on connectors that attach to a terminal strip for easy field wiring. The faceplate connector socket and cable plug are keyed to prevent the cable from being plugged into the wrong module.

On the back of the module are two edge connectors that attach to the system backplane.

2.2 Electrical Description

The input module contains 16 input circuits for 24 volt control signals. Each group of four circuits shares a single isolated common. Input signals have 2500 volt isolation to logic common. Refer to the block diagram in Appendix B.

Each input circuit consists of a current limiting resistor, a full wave bridge rectifier, an optical isolator, and a filter to eliminate spurious signals. A circuit diagram is shown in figure 2.1.




Figure 2.1- Typical Input Circuit

There are 16 LED indicators on the faceplate of the module. They are numbered sequentially from zero through 15, corresponding to the bits in the register. See figure 2.2.

The LED indicators display the status of the logic level circuitry. A lit LED indicates that both the input circuit and the logic level circuitry are operating correctly.




Figure 2.2- Module Faceplate

3.0 INSTALLATION

This section describes how to install and remove the module and its cable assembly.

3.1 Wiring

The installation of wiring should conform to all applicable codes.

To reduce the possibility of electrical noise interfering with the proper operation of the control system, exercise care when installing the wiring from the system to the external devices. For detailed recommendations refer to IEEE 518.

3.2 Initial Installation

Use the following procedure to install the module:

- Step 1. Turn off power to the system. All power to the rack as well as all power to the wiring leading to the module should be off.
- Step 2. Mount the terminal strip (M/N 57C370) on a panel. The terminal strip should be mounted to permit easy access to the screw terminals. Make certain that the terminal strip is close enough to the rack so that the cable will reach between the terminal strip and the module.
- Step 3. Fasten field wires to the terminal strip. Typical field connections are shown in figure 3.1.

Refer to Appendix C for the arrangement of terminal board connections. Make certain that all field wires are securely fastened.




Figure 3.1 - Typical Field Signal Connections

- Step 4. Take the module out of its shipping container. Take it out of the anti-static bag, being careful not to touch the connectors on the back of the module.
- Step 5. Insert the module into the desired slot in the rack. Refer to figure 3.2. Use a screwdriver to secure the module into the slot.




Figure 3.2- Rack Slot Numbers

- Step 6. Attach the field terminal connector (M/N 57C370) to the mating half on the module. Make certain that the connector keys are oriented properly and that the connector is the proper one for this module. Use a screwdriver to secure the connector to the module.

Note that both the module and the terminal strip connector are equipped with “keys.” These keys should be used to prevent the wrong cable from being connected to a module in the event that the connector needs to be removed for any reason and then reattached later.

At the time of installation, rotate the keys on the module and the connector so that they can be connected together securely. It is recommended that, for modules so equipped, the keys on each successive module in the rack be rotated one position to the right of the keys on the preceding module.

If you use this method, the keys on a particular connector will be positioned in such a way as to fit together only with a specific module, and there will be little chance of the wrong connector being attached to a module.

- Step 7. Turn on power to the system.
- Step 8. Verify the installation by connecting the programming terminal to the system and running the ReSource Software.

Stop all programs that may be running.

Use the I/O MONITOR function. If the module is in the local rack, enter the input module slot number and register (always 0).

If the module is in a remote rack, enter the slot number of the master remote I/O module, remote I/O drop number (also called the remote rack number), input module slot number, and register (always 0).

Toggle each of the input devices connected to the input module one at a time to verify that the installation has been completed correctly.

3.3 Module Replacement

Use the following procedure to replace a module:

- Step 1. Turn off power to the rack and all connections.
- Step 2. Use a screwdriver to loosen the screws holding the connector to the module. Remove the connector.
- Step 3. Loosen the screws that hold the module in the rack. Remove the module from the slot in the rack.
- Step 4. Place the module in the anti-static bag it came in, being careful not to touch the connectors on the back of the module. Place the module in the cardboard shipping container.
- Step 5. Take the new module out of the anti-static bag, being careful not to touch the connectors on the back of the module.
- Step 6. Insert the module into the desired slot in the rack. Use a screwdriver to secure the module into the slot.
- Step 7. Attach the field terminal connector (M/N 57C370) to the mating half on the module. Make certain that the connector keys are oriented correctly and that the connector is the proper one for this module (see step 6 in 3.2 Initial Installation). Use a screwdriver to secure the connector to the module.
- Step 8. Turn on power to the rack.

4.0 PROGRAMMING

This section describes how data is organized in the module and provides examples of how the module is accessed by the application software. For more detailed information, refer to the AutoMax Enhanced BASIC Language Instruction Manual (J-3675).

4.1 Register Organization

The data in the module is organized as one 16 bit register. The software allows you to define the module as a single register (up to 16 bits) by referencing the entire module as a unit, or as up to 16 individual bits by treating each of the bits separately. Refer to figure 4.1.




Figure 4.1- Organization of Register Bits

4.2 Configuration

Before any application programs can be written, it is necessary to configure, or set, the definitions of system-wide variables, i.e. those that must be globally accessible to all tasks.

For DCS 5000 and AutoMax Version 2.1 and earlier, you define system-wide variables by writing a Configuration task. For AutoMax Version 3.0 and later, you define system-wide variables using the AutoMax Programming Executive. After these variables are defined, you can generate the configuration file automatically, which eliminates the requirement to write a configuration task for the rack. If you are using AutoMax Version 2.1 or earlier, refer to Appendix E for examples that show how to define variables in the configuration task. If you are using AutoMax Version 3.0 or later, see the AutoMax Programming Executive (J-3750) for information about configuring variables.


4.3 Reading Data In Application Tasks

In order for an input module to be referenced by application software, it is necessary to assign symbolic names to the physical hardware. This is accomplished by either IODEF or RIODEF statements in the configuration task.

Each application program that references the symbolic names assigned to the input module in configuration must declare those names COMMON.

The frequency with which tasks read their inputs and write their outputs depends on the language being used. Ladder logic and control block tasks read inputs once at the beginning of each scan and write outputs once at the end of scan. BASIC tasks read an input and write an output for each reference throughout the scan.

4.3.1 Ladder Logic Task Example



The symbolic names LIGHT and STARTPB reference the input modules. The trailing at symbol “@” is not used in ladder logic tasks. The symbolic name “run” is local to the ladder logic task and does not have I/O associated with it.

4.3.2 BASIC Task Example

```
1000      COMMON      LIGHT@      \!Fault Light
1010      COMMON      STARTPB@     \!Start Push-button
2000      LOCAL RUN@
3000      !
4000      !
5000      RUN@ = NOT LIGHT@ AND ( STARTPB@ OR RUN@)
5500      !
6000      END
```

The symbolic names LIGHT@ and STARTPB@ reference the input modules. The symbolic name RUN@ is local to the BASIC task and does not have I/O associated with it.

4.3.3 Control Block Task Example

```
2400      COMMON STARTPB@      \!Start push-button
2500      LOCAL MOMENTARY@     \!Momentary output
3000      !
5000      CALL TRANSITION( INPUT=STARTPB@,
                          OUTPUT=MOMENTARY@)
5500      !
6000      END
```

The symbolic name STARTPB@ references the input module. The symbolic name MOMENTARY@ is local to the control block task and does not have I/O associated with it.

4.4 Restrictions

This section describes limitations and restrictions on the use of this module.

The 24V A-C/D-C Input Module is a read only module. Attempts to write to it will cause a bus error (severe system error). The following are examples from programs that write to the module and should therefore be avoided:

- a. Referencing the module from a coil in a ladder logic task.
- b. Referencing the module on the left side of an equal sign in a LET statement in a control block or BASIC task.
- c. Referencing the module as an output in a control block function.

5.0 DIAGNOSTICS AND TROUBLESHOOTING

This section explains how to troubleshoot the module and field connections.

5.1 Incorrect Data

Problem: The data is either always off, always on, or different than expected. The possible causes of this are a module in the wrong slot, a programming error, or a malfunctioning module. It is also possible that the input is either not wired or wired to the wrong device. Use the following procedure to isolate the problem:

Step 1. Verify that the input module is in the correct slot and that the I/O definitions are correct.

Refer to figure 3.2. Verify that the slot number being referenced agrees with the slot number defined in the configuration task. For this module, the register number is always zero. Verify that the bit number refers to the proper bit. Note that the bit number and the wire number are not the same.

For remote I/O installations, also verify that the master slot and remote drop number are defined correctly.

Step 2. Verify that the input is wired to the correct device.

Confirm that all connections at the terminal strip are tight. Connect a voltmeter to the proper points on the terminal strip and toggle the device. The voltmeter should alternate between 0 and 115 volts. If this does not happen, there is a problem with either the external device, the DC power supply, or the wiring to the terminal strip.

Check the cable for continuity between the faceplate connector and the terminal strip.

Step 3. Verify that the module can be accessed.

Connect the programming terminal to the system and run the ReSource Software. Use the I/O MONITOR function. Toggle the input device to determine whether the bit is changing state.

If the programmer is able to read the input, the problem lies in the application software (proceed to step 4). If the programmer cannot read the inputs, the problem lies in the hardware (proceed to step 5).

Step 4. Verify that the user application program is correct.

Verify that the application program that references the symbolic names associated with the module has declared those names COMMON in application tasks.

Verify that the symbolic name in question is being referenced in the application program. This can be done indirectly by monitoring the name with the VARIABLE MONITOR function in the ReSource Software.

If operation is intermittent, verify that the program reading the module is executing fast enough to catch all of the input changes.

Step 5. Verify that the hardware is working correctly.

Toggle the input device. Verify that the LED associated with the particular bit is also toggling. If it is not, the input circuit on the module is malfunctioning.

Verify the hardware functionality by systematically swapping out modules. After each swap, if the problem is not corrected, replace the original item before swapping out the next item.

- To test local I/O, first replace the input module. Next, replace the processor module (s). If the problem persists, take all of the modules out of the backplane except one processor module and the input module. If the problem is now corrected, one of the other modules in the rack is malfunctioning. Reconnect the other modules one at a time until the problem reappears. If none of these tests reveals the problem, replace the backplane.
- To test remote I/O, first verify that the remote I/O system is communicating with the drop that contains the input module being tested. Next, determine whether the input module is the only module that is not working. If more than one module is not working correctly, the problem most likely lies in the remote I/O system. If the problem does not lie in the system, it probably involves the remote rack.
- To test the remote rack, first replace the input module. Next, replace the slave remote I/O module. If the problem persists, take all of the modules out of the remote backplane except the slave remote I/O module and the input module. If the problem is now corrected, one of the other modules in the rack is malfunctioning. Reconnect the other modules one at a time until the problem reappears. If the problem proves to be neither in the remote I/O system nor in the remote rack, try replacing the backplane.

5.2 Bus Error

Problem: A “31” or “51” through “58” appears on the processor module’s LED. This error message indicates that there was a bus error when the system attempted to access the module. The possible causes of this error are a missing module, a module in the wrong slot, or a malfunctioning module. It is also possible that the user is attempting to write to the wrong registers on the module. Refer to the DCS 5000 Processor Module Instruction Manual (J-3635) or AutoMax Processor Module Instruction Manual (J-3650) for more information. Use the following procedure to isolate a bus error:

Step 1. Verify that the input module is in the correct slot and that the I/O definitions are correct.

Refer to figure 3.2. Verify that the slot number being referenced agrees with the slot number defined in the

configuration task. Verify that the register number and bit number are correct.

For remote I/O installations, also verify that the master slot and remote drop number are defined correctly.

Step 2. Verify that the module can be accessed.

Connect the programming terminal to the system and run the ReSource Software. Use the I/O MONITOR function to display register 0. If the programmer is able to monitor the inputs, the problem lies in the application software (proceed to step 3). If the programmer cannot monitor the inputs, the problem lies in the hardware (proceed to step 4).

Step 3. Verify that the user application program is correct.

This module cannot be written to. If a BASIC task caused the bus error, the error log will contain the statement number in the task where the error occurred. If a ladder logic or control block task caused the error, you will need to search the task for any instances where you used an input as a ladder logic coil or wrote to it in a control block task.

Step 4. Verify that the hardware is working correctly.

Verify the hardware functionality by systematically swapping out the input module, processor module(s), and backplane. After each swap, if the problem is not corrected, replace the original item before swapping out the next item.

For remote I/O installations, systematically swap out the input module, the slave remote module, and the backplane. After each swap, if the problem is not corrected, replace the original item before swapping out the next item.

Appendix A

Technical Specifications

Ambient Conditions

- Storage temperature: -40C - 85C
- Operating temperature: 0C - 60C
- Humidity: 5-90% non-condensing

Maximum Module Power Dissipation

- 30 Watts

Dimensions

- Height: 11.75 inches
- Width: 1.25 inches
- Depth: 7.375 inches

System Power Requirements


- +5 volts: 625 ma

Input Circuit

- Number of Inputs: 16
- Maximum operating voltage: 30 volts rms
- Minimum turnon voltage: 8.4 volts rms
- Maximum turnoff voltage: 2.2 volts rms
- Input current: 7.0 ma at 8.4 volts
34.2 ma at 30 volts
- Maximum input delay: 20 msec at 50 hertz
18 msec at 60 hertz
8 msec at D-C
- Four Inputs per isolated common
- 2500 volt isolation between logic common and input power

Appendix B

Module Block Diagram



Appendix C

Field Connections


Terminal Board Number	Reg. 0 Bit
1	0
2	1
3	2
4	3
5 (common)	
6	4
7	5
8	6
9	7
10 (common)	
11	8
12	9
13	10
14	11
15 (common)	
16	12
17	13
18	14
19	15
20 (common)	

Appendix D

Related Components

57C370 – Terminal Strip/Cable Assembly

This assembly consists of a terminal strip, cable, and mating connector. It is used to connect field signals to the faceplate of the input module.




Appendix E

Defining Variables in the Configuration Task

Local I/O Definition

This section describes how to configure the input module when it is located in the same rack (i.e., the local rack) as the processor module that is referencing it. Refer to the figure below. Note that this procedure is used only if you are using the AutoMax Programming Executive software version 2.1 or earlier.



Single Register Reference

Use the following method to reference all 16 inputs as a single register. Only one statement is necessary in the configuration task for the entire module. The symbolic name of the register should be as meaningful as possible:

```
nnnnn IODEF SYMBOLIC_NAME%[ SLOT=s, REGISTER=0]
```

Bit Reference

Use the following method to reference individual inputs on the module. A maximum of 16 statements can be included in the configuration task (one for each bit). The symbolic name of each bit should be as meaningful as possible:

```
nnnnn IODEF SYMBOLIC_NAME@[ SLOT=s, REGISTER=0, BIT=b]
```

where:

nnnnn – BASIC statement number. This number may range from 1-32767.

SYMBOLIC_NAME% – A symbolic name chosen by the user and ending with (%). This indicates an integer data type and all references will access the entire module.

SYMBOLIC_NAME@ - A symbolic name chosen by the user and ending with (@). This indicates a boolean data type and all references will access bit number “b” only.

SLOT – Slot number that the module is plugged into. This number may range from 0–15.

REGISTER – Always zero for this module.

BIT – Used with boolean data types only. Specifies the bit in the register that is being referenced. This number may range from 0–15.

Examples Of Local I/O Definitions

The following statement assigns the symbolic name POSITION% to the input module located in slot 4:


```
1020 IODEF POSITION%[ SLOT=4, REGISTER=0]
```

The following statement assigns the symbolic name LIGHT to bit 9 on the input module located in slot 7:

```
2050 IODEF LIGHT@[ SLOT=7, REGISTER=0, BIT=9]
```

Remote I/O Definition

This section describes how to configure the module when it is located in a rack that is remote from the processor module referencing it. Refer to the figure below.



Module in a Remote Rack

Single Register Reference

Use the following method to reference all 16 bits as a single register. Only one statement is required in the configuration task for the entire module. The symbolic name of the register should be as meaningful as possible:

```
nnnnn RIODEF SYMBOLIC_NAME%[ MASTER_SLOT=m, DROP=d, SLOT=s,  
REGISTER=0]
```

Bit Reference

Use the following method to reference individual bits on the module. A maximum of 16 statements can be included in the configuration task (one for each bit). The symbolic name of each bit should be as meaningful as possible:

```
nnnnn RIODEF SYMBOLIC_NAME@[ MASTER_SLOT=m, DROP=d,  
SLOT=s, REGISTER=0, BIT=b]
```

where:

nnnnn – BASIC statement number. This number may range from 1–32767.

SYMBOLIC_NAME% – A symbolic name chosen by the user and ending with (%). This indicates an integer data type and all references will access the entire module.

SYMBOLIC_NAME@ – A symbolic name chosen by the user and ending with (@). This indicates a boolean data type and all references will access bit number “b” only.

MASTER_SLOT – Slot number that the master remote I/O module is plugged into. This number may range from 0-15.

DROP – Drop number of the slave remote I/O module that is in the same rack as the input module. This number may range from 1–7.

SLOT – Slot number that the module is plugged into. This number may range from 0–15.

REGISTER – Always zero for this module.

BIT – Used with boolean data types only. Specifies the bit in the register that is being referenced. This number may range from 0–15.

Examples Of Remote I/O Definitions

The following statement assigns the symbolic name LEVEL% to the input module located in slot 4 of remote I/O drop 3. This remote drop is connected to the remote I/O system whose master is located in slot 15 in the master rack:

```
1020 RIODEF LEVEL% [ MASTER_SLOT=15, DROP=3, .SLOT=4,  
REGISTER=0]
```

The following statement assigns the symbolic name STARTPB@ to bit 9 on the input module located in slot 7 of remote I/O drop 2. This remote drop is connected to the remote I/O system whose master is located in slot 6 in the master rack:

```
2050 RIODEF STARTPB@[ MASTER_SLOT=6, DROP=2, SLOT=7,  
REGISTER=0, BIT=9]
```


For additional information

1 Allen-Bradley Drive

Mayfield Heights, Ohio 44124 USA

Tel: (800) 241-2886 or (440) 646-3599

<http://www.reliance.com/automax>

www.rockwellautomation.com

Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433
Europe/Middle East/Africa: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741
Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 6356-9077, Fax: (65) 6356-9011